Click to verify

The Secure Print function allows you to set a document ID and a password for print data and to save the data in a box (Secure Print User Box) on this machine. Because the data is not printed soon, this function prevents printed materials from being missing or left unattended.Since you need to enter the document ID and password from the Touch Panel to print the data saved in the box, this function is particularly suitable for safely printing highly confidential documents.If simple printing for secure print document is enabled, the computer login name is used as the document ID for Secure Print, so you can skip the entry of the document ID.Also, if the computer login name is used as the document ID for Secure Print, it prevents the document ID from being duplicated with that of another user, which simplifies document management on this machine.When making prints on the machine, the user can display a list of document IDs on the Control Panel and easily specify the target document ID.To enable simple printing for secure print document, configure the following settings.Select [Utility] - [Administrator Settings] - [System Settings] - [User Box Settings], then set [Security Document Setting] to [Release Secure Print] (default: [Do Not Release Secure Print]).In [Device Option] of the [Configure] tab of the printer driver, set [Security Document Setting] to [Release Secure Print] (default: [Do Not Release Secure Print]). For details on [Device Option], refer to [Configuring the optional environment of this machine] .TipsWhen simple printing is disabled, the document ID can be specified using up to 16 characters. If simple printing is enabled, the document ID can be extended to up to 64 characters.If simple printing is changed from Enable to Disable while the document ID is specified using 17 or more characters, it will cause document operations to fail.A single job allows you to print out a document of up to 2999 pages in length.In [Output Method] on the [Basic] tab, select [Secure Print].Enter the document ID and password, then click [OK].If you always use the same document ID and password, registering them in advance eliminates the need for entering them each time. For details, refer to [Changing the default print settings] .Execute printing.The data is saved in the Secure Print User Box. Continue to "Operations on this machine".You can issue a print instruction from the Control Panel before print data scanning on this machine is completed. However, printing is executed after print data scanning on this machine has been completed.Set passwords for print jobs using the printer driver from a computer. Enter the password on AccurioPro Print Manager when you print. With this feature, the job is erased after the print is complete, making it particularly useful for protecting confidential documents.In this section, PS Plug-in Driver is used as an example.3Select a file and print it.Page 2Only users registered via machine authentication or external server authentication can print authenticated prints.TipsIf you enter a username and password not registered on the system using [User Authentication] and try to print, or if you do not select [User Authentication] and try to print, the system does not authenticate and the job is discarded.Even if the user is registered, if they do not have permission to print they are still unable to print. For details about [User Authentication], contact the system administrator.This section describes the process using PS Plug-in Driver as an example.Page 3Set a password when scanning to encrypt the scan data. It is necessary to enter the password to browse the data. This is useful for protecting against data leaks.NOTICEMake sure you do not forget the password you set.TipsIn [File Type], select [PDF] + [Package], or [PDF] + [Divided] to encrypt the data.Cannot be encrypted for JPEG, XPS, TIFF or PDF compliant with PDF/A.Partitions cannot be configured if [HDD Encryption Setting] is enabled.Page 4You can set to prevent users, other than the owner of the job, from operating or removing a job.NOTICEThe settings detailed below are required to use this function.Set [User Authentication] to [Authenticate]TipsWhen [Enhanced Security Mode] is set to [ON], [Job Access Authority Setting] is automatically set to [Restrict].Page 5Touch panel can be configured on the system not to display personal information such as user name or address.This setting can protect your personal information.Page 6[Quick IP Filtering]Page 7You can store job data on the HDD of this system on an external storage device, and restore any such previously stored data. This feature is a safety measure in case data is accidentally lost, or for if you want to restore the system to a previous state.For details about the back up function and restore function, refer to [HDD Restore/Backup].TipsIf Security Enhanced Mode is selected, [HDD Restore/Backup] is grayed out (inactive) and cannot be selected.5When complete, set the Sub power switch OFF/ON.Backup or restore only the jobs among the HDD store jobs that are saved in the backup folder directly under the Public folder.5When complete, set the Sub power switch OFF/ON.Page 8Select [Erase Mode] to overwrite and delete the data from HDD or non-volatile memory of the system or image controller with specific data. Overwrite and delete the data to safely dispose of the HDD.NOTICEIf you delete using [Execute Deletion], you cannot reuse any of the data on the HDD. Make sure you store any vital data to a separate device in advance.TipsContact your service representative if you intend to use this feature.Overwrite with a single-byte random number - Overwrite with a single-byte random number - Overwrite with 0x00Overwrite with 0x00 - Overwrite with a 0xff - Overwrite with a single-byte random numberOverwrite with a single-byte random number - Overwrite with a 0x00 - Overwrite with 0xffOverwrite with 0x00 - Overwrite with a 0xff - Overwrite with 0x00 - Overwrite with 0xffOverwrite with 0x00 - Overwrite with a 0xff - Overwrite with 0x00 - Overwrite with 0xffOverwrite with 0x00 - Overwrite with a 0xff - Overwrite with 0x00 - Overwrite with a 0xff - Overwrite with 0x00 - Overwrite with a 0xff - Overwrite with 0x00 - Overwrite with a 0xff - Overwrite with 0xff - Overwrite with 0x00 - Overwrite with a 0xff - Overwrite with 0xaa - Verification3Press [Execute Deletion].3Press [Execute Deletion].Page 9It is necessary to connect to the relevant networks when using the scan function, or the print function of the system using the Image Controller.Firstly, prepare your setup so that you are able to connect the system to a network.This section describes the preparations required for connecting to a network.Insert a network cable into the system's NIC.Insert a network cable into the Image Controller's NIC.Check that the NIC light (lower) is on.Configure the IP address.Refer to [IPv4 Settings] if using IPv4.Refer to [IPv6 Settings] if using IPv6.Check that communications are happening on the network without issues. For details, refer to [PING Confirmation].Page 10Configure settings for using the system while connected in a TCP/IP environment.In particular, you can check and configure IP addresses, set up DNS servers, and configure IPSec if necessary.Use IPv4 when you want to set an IP address "xxx.xxx.xxx.xxx" on the system.NOTICEDo not set the following combination for IPv4.IP address: 203.0.113.14Press [IPv4 Settings] and then select [Manual Input] or [Auto Input].[Manual Input]: Manually configure the IP address (if required, you can also configure the subnet mask and default gateway).[Auto Input]: The IP address is assigned automatically. As such, you do not need to manually set the IP address.3Press [Direct Setting] or [Auto Setting] on the [IP Address Set Method].[Direct Setting]: Manually configure the IP address (if required, you can also configure the subnet mask and default gateway).[Auto Setting]: The IP address is assigned automatically. As such, you do not need to manually set the IP address.Page 11Configure settings for using the system while connected in a TCP/IP environment.In particular, you can check and configure IP addresses, set up DNS servers, and configure IPSec if necessary.Use IPv6 when you want to set an IP address "xxxx.xxxx.xxxx.xxxx.xxxx.xxxx.xxxx.xxxx" on the system.4Press [IPv6 Settings], and configure the various items.3Press [Next], and configure the various items.Page 12Check that the "PING" command is sent from the system.4If sent successfully, a message is displayed saying "PING completed successfully".If there were any issues in the communication, a message such as "Check the connection and settings" is displayed.Page 13You can use the system as a printer and print over a network. The protocols used for connecting to the system may differ depending on the operating environment.TipsProtocols are rules for sending and receiving data between devices over a network.Included on Windows as standard, so it is easy to use. There are only a few items to configure on the system.Directly specify the RAW port on the system (9100 by default) and print via the network. It can be used when "Standard TCP/IP Port" is selected during installation.Minimal load on the network. It is easy to intuitively (name) find this system.Enable Bonjour on the system to enable MacOS computers to automatically detect the systems connected to your network over TCP/IP without having to use a DNS server, and to display a list of those systems that can be added as printers.Can be used on both Windows and Mac.Prints over a network using the LPR (Line Printer Daemon) protocol.Extremely simple to install.Use web service functions that are available on Windows computers to enable the automatic detection of systems connected to your network, making their installation as web service printers extremely simple.Minimal load on the computer itself.SMB printing is a function for printing from a computer by directly specifying individual systems. The SMB (Server Message Block) protocol is used for sharing the system.As the system can also be used outside of a LAN environment, it can even access printers located outside the company network.IPP printing is a function that allows you to print over a network using IPP protocols.Among the protocols, it is in the position of "application protocol"*.IPP, which is an extension of the HTTP protocol, is used to transfer the print data, allowing printing to be performed using remotely located printers over the Internet without being blocked by firewalls.You can enhance printing security by performing authentication during printing and encrypting data using SSL.*Application Protocol: A type of communications standard (protocol). Individually established according to the type of specific application, software, or service, etc.Page 14The system can be used as a network scanner. Scan data can be scanned into a network-connected computer using a variety of methods.Can be used in external environments. Simply scan the data and wait for the email to arrive. No further actions or settings required after scanning.Data scanned by the system is received as an email.As the data is stored in the machine's HDD, there is no need to worry about linking to another server.Data scanned by the system is stored in the system's HDD, and then downloaded to a computer. A dedicated application (HDD TWAIN Driver) is required for downloading the data.FTP servers already being used in your workplace can be used as-is without further modification. Can be used in external environments.Data scanned by the system is uploaded to the specified FTP server.Does not use any special hardware, making it easy to use. Using "browsing" helps reduce time-consuming file path entry work.Data scanned by the system is stored in the specified shared (SMB) folder.In addition to functions similar to FTP, you can also edit over the server.Data scanned by the system is uploaded to the specified WebDAV server.Page 15Connect the system to the network to allow use of a variety of applications on your computer. Using the useful management functions on the application allows you to operate the system more efficiently.Required Network SettingsIP address ([TCP/IP Settings])Mainly a color management utility for the machine that allows the sequential adjustment (maximum density, density balance, etc.) of image quality in a step by step manner.Download from the specified URL and installIP address ([TCP/IP Setting])An application for acquiring information regarding the status of the machine, managing jobs, and editing hold jobs.Access from the system's IP addressIP address ([TCP/IP Settings])A tool for direct printing of files such as PDFs and TIFFs without having to boot up the application.Download from the specified URL and installIP address ([TCP/IP Settings])A tool for checking the status of the machine and setting up networks.Access from the system's IP addressIP address ([TCP/IP Settings])A device management utility that allows you monitor multiple copiers and to remotely operate the control panel of the machine in real time.Access from the system's IP addressIP Addresses ([TCP/IP Setting])JSP Port Numbers ([JSP Setting])A color management utility for controllers that can be used to perform calibration, edit tone curves, manage spot colors and alternative colors, etc.Download from the IP address of the Image Controller and installPage 16Practical GuideExplains examples of using this machine.Page 17This product includes the following manual.Describes precautions and requests you should observe in order to use this system safely.Be sure to read this manual before using this product.ReferenceFor details about the default administrator password, refer to [About the Administrator Password].This guide is intended for people ranging from users who are using this system for the first time to system administrators.This guide describes the basic operation procedures of this system, useful functions, maintenance method, simple troubleshooting method, and setting methods of this system.Basic technical knowledge of the product is required for maintenance and troubleshooting. Be sure to perform maintenance and troubleshooting within the scope described in the manual.Should you need any help, contact your service representative.Page 18For details about the recommended operating systems and browsers for the User's Guide, access the following URL. viewing the guidance of the recommended operating systems and browsers, check [Version] at the bottom of the top page of the User's Guide, and refer to the description of the target version.Descriptions of recommended operating system and browser versions that we have verified as operational are included.1,024 e 768 Pixel or higherJavaScript is mainly used for the following functions.SearchContents operationLink modalBe sure to always enable JavaScript. If disabled, some functions will become unavailable.The setting method varies depending on the browser you are using. Follow the setting method for each browser to check and configure settings.Please note that the specified function may not work correctly depending on your system environment. Use of the latest browser will enable you to resolve problems in some cases.Page 19Describes information the user(s) needs to know before using this system.This item allows you to check how to turn the power on, install or uninstall an application, load paper into a tray, and add or replace consumables.Describes the name and specifications of each component of the machine or optional device.Presents various guides to enable efficient use of this system.This item describes practical system use methods ranging from basic usage to the function application.Describes the functions of the Control panel and Touch panel on the machine, and various screens displayed on the Touch panel.Describes the functions of PS Plug-in Driver.Describes the functions of each application such as Web Connection or Web Utilities.Allows you to check the update history of the User's Guide.Allows you to check the terms of use of the User's Guide.Used to search for the entire User's Guide using any keyword.Using the Refine search function allows you to further filter the search result.For details, refer to Using the Search Function.Describes how to use the User's Guide as well as notations in the text.Allows you to confirm the appropriate action if you have any questions or problems regarding use of this system.Displays a list of pages registered in Bookmark. This item allows you to display or delete a page in Bookmark.For details, refer to Using the Bookmark Function.Click this to access the Konica Minolta website.Selecting each page displays the Contents bar in the left-hand pane. The contents has a tree structure.Clicking a contents title expands the tree. Re-clicking collapses the tree.To collectively operate all the displayed trees, click [Expand all] or [Collapse all].To hide the Contents bar, click "" in the upper right of the Contents bar. When the Contents bar is hidden, the icon changes to "". To display the Contents bar again, click "".Clicking each menu in the User's Guide displays content in the text page.You can also click an icon or link at the top of the screen to move to another page or register the displayed page in Bookmark.Click this item to display the menu of the User's Guide in a pop-up window. Clicking a menu name jumps to the target menu.If you place the cursor over a menu name containing "", the menu names in the next hierarchy are also displayed.Click this item to return to the top page (home).Shows the hierarchy of the currently displayed page. Clicking the underlined hierarchy jumps to the target page.Clicking this item changes the icon color to yellow, and registers the displayed page in Bookmark.If you click "", the page is removed from Bookmark.For details about Bookmark, refer to Using the Bookmark Function.Click this item to print the currently displayed page.Clicking "" returns to the previous page.Clicking "" proceeds to the next page."" is grayed out in the first page, and "" isgrayed out in the last page.Clicking "" jumps to the top of the displayed page.Clicking "" jumps to the bottom of the displayed page.Depending on the display position of the page, only one of them may be displayed.NOTICEIf you directly operate a reference link in the text and display it in a new window or new tab, an error may occur. When opening a reference link, click it to open the page.If you click a reference link in the text, the linked page opens with a modal window. If you further click a reference link in the modal window, the linked page opens as a new tab in the window.Switching the tab displays the source page in which a modal window was opened.[Display table of contents]Click this item to display the page displayed with a modal window as a new tab of a new window. The Contents bar of the selected category will be displayed on the left-hand pane of the screen.Click this item to print the currently displayed page with a modal window.Closes the entire modal window.If a reference link in the text is connected to the contents, the Contents page opens with a modal window. Clicking a contents title opens the item as a new tab in the window.Page 20Used to search for the entire User's Guide using any keyword.Using the Refine search function allows you to further filter the search result.For details, refer to Using the Search Function.Displays a list of pages registered in Bookmark. This item allows you to display or delete a page in Bookmark.For details, refer to Using the Bookmark Function.Describes information the user(s) needs to know before using this system.This item allows you to check how to turn the power on, install or uninstall an application, load paper into a tray, and add or replace consumables.Describes the name and specifications of each component of the machine or optional device.Presents various guides to enable efficient use of this system.This item describes practical system use methods ranging from basic usage to the function application.Describes the functions of the Control panel and Touch panel on the machine, and various screens displayed on the Touch panel.Describes the functions of PS Plug-in Driver.Describes the functions of each application such as Web Connection or Web Utilities.Describes how to use the User's Guide as well as notations in the text.Allows you to confirm the appropriate action if you have any questions or problems regarding use of this system.Allows you to check the update history of the User's Guide.Allows you to check the terms of use of the User's Guide.Tap this to access the Konica Minolta website.If you tap "" displayed on the upper left of each page, the Contents bar is displayed in the left-hand pane. The contents has a tree structure.Tapping a contents title expands the tree. Re-tapping collapses the tree.To collectively operate all the displayed trees, tap [Expand all] or [Collapse all].When the Contents bar is displayed, the icon changes to "". To hide the Contents bar, tap "".Tapping each menu in the User's Guide displays content in the text page.You can also tap an icon or link at the top of the screen to move to another page or enter a keyword in the search field to search for the target in the User's Guide.Tap this item to display the menu of the User's Guide in a pop-up window. Tapping a menu name jumps to the target menu.Tap this item to return to the top page (home).Shows the hierarchy of the currently displayed page. Tapping the underlined hierarchy jumps to the target page.Tapping this item changes the icon color to yellow, and registers the displayed page in Bookmark.If you tap "", the page is removed from Bookmark.For details about Bookmark, refer to Using the Bookmark Function.Tapping "" returns to the previous page.Tapping "" proceeds to the next page."" is grayed out in the first page, and "" is grayed out in the last page.Tapping "" jumps to the top of the displayed page.Tapping "" jumps to the bottom of the displayed page.Depending on the display position of the page, only one of them may be displayed.NOTICEIf you directly operate a reference link in the text and display it in a new window or new tab, an error may occur. When opening a reference link, tap it to open the page.If you tap a reference link in the text, the linked page opens with a modal window. If you further tap a reference link in the modal window, the linked page opens as a new tab in the window.Switching the tab displays the source page in which a modal window was opened.Closes the entire modal window.[Display table of contents]Tap this item to display the page displayed with a modal window as a new tab of a new window. To display the Contents bar again, tap "".If a reference link in the text is connected to the contents, the Contents page opens with a modal window. Tapping a contents title opens the item as a new tab in the window.Page 21Enter any keyword in the search field, and click or tap ""; you can search for the target in the User's Guide. The search result is displayed in the order in which the matching rate is higher.The visited link is displayed in purple on the search result page.Keyword search: Searches for the entered keyword.AND search: Delimit multiple keywords using a space when entering them. This function can filter information including all the entered keywords.Enter multiple keywords that are enclosed by single-byte double quotation marks ("); you can perform phrase searches for the enclosed keywords. For example, if is entered in the search field, a search is performed using 1 phrase, . By this function, a higher accurate search can be performed.Page 22Clicking or tapping [Refine search] displays the menu list for Refine search.If you select the check box of each item to search, you can filter the search result. Filtering the search result makes it easier to access the target information.Click or tap this item to display the menu list for Refine search.Filters the search range by function category.Displays a description of each filtering item.Filters the search range by location.Filters the search range by option.Clicking or tapping this item displays a modal window to select an option.Filters the search range by item title of the User's Guide.Clicking or tapping this item displays a modal window that enables you to select an item title.Clears all the specified filtering conditions.Searches for the target based on the specified filtering conditions.Filter the search range by function category. A keyword is searched in the range that includes the items of which the check box is selected.Filter the search range by location (function operation location or application). A keyword is searched in the range that includes the items of which the check box is selected.Filter the search range by option.Clicking or tapping [Filter by option] displays a modal window that enables you to select an option. Select the check boxes of the items you want to include in the search range, and click or tap [Add Conditions]; the items are set as search conditions.Filters the search range by item title of the User's Guide.Clicking or tapping [Filter by title] displays a modal window that enables you to select a title. Select the check boxes of the items you want to include in the search range, and click or tap [Add Conditions]; the items are set as search conditions.Page 23After searching for a keyword, you can further filter the search result.For details about the setting procedure, refer to Refine Search.When you are browsing on a computer, the setting area is displayed in the left-hand pane of the search result page.If you are browsing on a smartphone, tap [Refine search]; the setting area is displayed.Page 24Bookmark is a function that registers the currently displayed page in Bookmark, and allows the user to immediately access the page.Clicking or tapping [Bookmarks] in the User's Guide displays a list of registered pages, enabling you to easily view the target page.Up to 100 pages can be registered in Bookmark.TipsNote that the contents of Bookmark are deleted if cookies in the browser are cleared.If you click or tap "" on the page you want to register in Bookmark, the icon color changes to yellow, and the currently displayed page is registered in Bookmark.If you click or tap "", the page is removed from Bookmark.TipsNo page can be registered in Bookmark unless cookies in the browser are enabled. Check the setting in advance.If the number of pages registered in Bookmark exceeds 100 or the capacity is full, error message [You have reached the maximum number of bookmarks that can be registered. To register this page, delete a registered bookmark.] is displayed. Remove unnecessary bookmarks before registering new ones.Clicking or tapping [Bookmarks] in the User's Guide displays a list of registered pages.Clicking or tapping the desired item displays its page in the text page.You can collectively delete all the pages in Bookmark, or delete the selected page from Bookmark.Selects all the pages in Bookmark.Clears the check box in Bookmark, and releases the selection.Removes the selected page from Bookmark.Displays the pages registered in Bookmark. Clicking or tapping a page title displays its page.Select the check box of the target page, and click or tap [Remove from bookmarks]; the page is removed from Bookmark.Page 25Clicking "" on the upper right of the screen allows you to print the currently displayed page.In a modal window, you can print the currently displayed tab.Tips"" may not be displayed depending on the width of the browser screen.If you are browsing on a smartphone, the print function is not available.If you make a print from the print menu on the browser, printing may fail.Page 26This manual describes a machine equipped with scanner and HDD as an example unless otherwise noted.The optional Paper Feeder Unit PF-713 and Upgrade Kit UK-112 are required to use the scanner and HDD in this system.Note that the available items, functions, or screens may vary depending on whether this system is equipped with scanner and HDD.This manual describes the Touch panel screen of a machine equipped with scanner and HDD as an example.The initial display of the Touch panel screen is different on a machine that are not equipped with a scanner and HDD.The following keys are not displayed.[RECALL][STORE][COPY][SCAN] Users can change the password that an administrator has been set in combination with a user name (user password). The password changed in this setting is used in the user authentication.Password change is available on the machine if the user authentication is configured.To change the password, the correct user name and the current password are required. You can change the password only; user name cannot be changed here. The password paired with an account name (account password) cannot be changed.Follow the procedure onUser Settingto display the [User Setting Menu] screen.Press [Change Password] on the [User Setting Menu] screen.Press [User Name], then enter the registered user name. Press [OK].Press [Current Password], then enter the current password. Press [OK].Press [New Password], then enter a new user password. Press [OK].You may enter up to 64 one-byte characters for the user password.Press [Input Confirmation] to reenter the new password. Press [OK].Press [OK] to complete the setting.To cancel the change, press [Cancel]. In either case, the screen returns to the [User Setting Menu] screen. Once you have reset the admin password, you will be able to log in to the printers web interface and make any changes that you need to. If you are unable to locate the reset button on your Konica Minolta printer, or if you need further assistance, you can contact Konica Minolta customer support for assistance. Remember, resetting the admin password on your Konica Minolta printer is a serious step and should only be done as a last resort.The Konica Minolta printer is a high-quality printer that is known for its reliability and performance. However, like all printers, it can sometimes experience problems, such as forgetting the admin password. If this has happened to you, dont worry! In this article, we will show you how to reset the admin password on your Konica Minolta printer. Konica Minolta is a Japanese company that has been manufacturing printers for over 30 years. As with most printers, the Konica Minolta printer comes with an admin password that cannot be changed without the factory settings. However, if you forget the admin password, it is possible to reset it.To do this, you will need to locate the reset button on your Konica Minolta printer. The reset button is usually located on the back of the printer, near the power cord.Once you have located the reset button, press and hold it for 10 seconds. The printer will then restart and the admin password will be reset.It is important to note that the reset button will only work if you have forgotten the admin password. If you have lost the password, you will need to contact Konica Minolta for further assistance.Once you have reset the admin password, you will be able to log in to the printers web interface and make any changes that you need to.It is important to note that resetting the admin password will erase any custom settings that you have made to the printer. Therefore, it is important to back up any important settings before resetting the password.If you are unable to locate the reset button on your Konica Minolta printer, or if you need further assistance, you can contact Konica Minolta customer support for assistance. 1. Open the printers web interface.2. Go to the Settings or Maintenance menu.3. Look for the Reset or Initial Setup option.4. Follow the on-screen instructions to reset the password.5. Once the password is reset, you should be able to log in using the new password. If you forget the admin password for your Konica Minolta printer, there are several methods you can try to reset it. However, keep in mind that some of these methods may require technical expertise or the use of specialized tools.1. Check the manual: Your printers manual should include instructions on how to reset the admin password.2. Use the control panel: Some Konica Minolta printers have a control panel that allows you to reset the admin password. Look for a Reset or Clear button and press it.3. Use default passwords: Konica Minolta printers often have default passwords that you can use to access the admin settings. Try common passwords like admin, password, or 1234.4. Use specialized tools: If youre unable to reset the admin password using the previous methods, you can try using specialized tools like Konica Minoltas Service Tool. This tool allows you to reset the admin password and access the printers settings.5. Contact Konica Minolta support: If youre still unable to reset the admin password, you can contact Konica Minoltas customer support for assistance. They may be able to guide you through the reset process or provide further assistance.Remember, resetting the admin password on your Konica Minolta printer is a serious step and should only be done as a last resort. Be sure to take the necessary precautions to protect your personal information and data. Resetting the admin password on a Konica Minolta printer is a fairly straightforward process. Here are the steps you need to follow:1. Power off the printer and unplug it from the power source.2. Press and hold the Cancel button while plugging the printer back into the power source.3. Continue holding the Cancel button until the Select Function screen appears.4. Use the arrow keys to navigate to the Admin Settings option and press Enter.5. Use the arrow keys to select Change PW and press Enter.6. Use the arrow keys to select Yes and press Enter.7. Use the arrow keys to enter a new password and press Enter.8. Use the arrow keys to confirm the new password and press Enter.9. Use the arrow keys to select OK and press Enter.10. The printer will prompt you to enter a temporary password. Use the arrow keys to enter a temporary password and press Enter.11. The printer will now display a confirmation message indicating that the password has been successfully reset.12. Some common problems that users may encounter while resetting the admin password on their Konica Minolta printer include:1. Inability to access the printers web interface due to a forgotten password.2. Inability to locate the printers IP address, which is required for accessing the web interface.3. Inability to find the reset button, which is located on the printers control panel.4. Inability to reset the password using the reset button, due to incorrect button pressing or insufficient power supply.5. Inability to reset the password using the web interface, due to incorrect password entry or insufficient power supply.6. Inability to reset the password using the printers default settings, due to incorrect password entry or insufficient power supply.If you encounter any of these issues, please refer to the printers user manual or contact Konica Minolta customer support for assistance. To prevent your Konica Minolta printers admin password from being reset by unauthorized users, follow these steps:1. Enable the admin password: Go to your printers web interface and navigate to the Settings or Security menu. Look for an option to enable an admin password. Set a strong and unique password that is not easy to guess.2. Lock the web interface: After enabling the admin password, go to the web interfaces Settings or Security menu and look for an option to lock the web interface. This option will prevent unauthorized access to the web interface, even if the printers IP address is known.3. Enable SNMPv3: SNMP (Simple Network Management Protocol) is a protocol that allows network administrators to manage network devices, including printers. Enabling SNMPv3 (version 3) will provide additional security features such as authentication and encryption, making it harder for unauthorized users to access your printers configuration.4. Disable telnet and FTP: Telnet and FTP are protocols used for remote access to network devices. Disabling these protocols will prevent unauthorized users from connecting to your printer using these methods. Need to change Konica Minolta printer default password? Follow these simple steps to reset your Konica Minolta printer admin password. The Secure Print function saves a print job in the Secure Job box of the machine and users need to enter passwords on the touch panel to output the job. This function is very useful for printing confidential documents.The Secure Print function can be specified using the printer driver when printing, and printing can be performed from the touch panel.In order to prevent information leakage, you can restrict printing done on this machine to secure printing only.Click the Workflow tab.Select Secure Print from the Output Method pull-down menu.At this time, Normal is automatically selected for Print Mode.Enter the Secure Print ID and Password. To specify the password, type Password, then enter the same password in Reenter.supplementary explanationPassword: 1 to 8 one-byte charactersClick OK to make prints.On the touch panel, press JOB LIST and then press Secure Job.Select the name that has the Secure Print ID specified on the printer driver for printing.Enter a set password in Secure Print, and then press OK.The print jobs in the User Box are displayed.Select a print job, then click Output.A dialog is displayed to specify the output method and number of copies.Select the desired one from Normal, Proof, Proof(1st), and Wait, enter the number of copies using the keypad on the control panel, then press OK.When print-out processing is completed, the print job is deleted from the User Box.For details about job editing functions on the JOB LIST screen, such as HDD Store, refer to [Secure Job] Screen. Open the file in the application, and click [File]. Then click [Print] from the menu.Select this product from [Select Printer] (or [Printer Name]) then click [Preferences] (or [Properties]).In [Output Method] on the [Basic] tab, select [Secure Print].Enter the [Secure Print ID] and [Password], then click [OK].Click [OK].Click [Print].Tap [User Box] and select [Secure Print] from [System].Enter the ID and password for the secure print document, then tap [OK].Select a secure print document, then tap [Print].Change theprint settings as necessary, and press theStartkey on the Control Panel.The secure print document is printed and automatically cleared from the Secure Print User Box.Open the file in the application, and click [File]. Then click [Print] from the menu.Select this product from [Select Printer] (or [Printer Name]) then click [Preferences] (or [Properties]).On the [Basic] tab, click [Authentication/Account Track].Select [Recipient User], enter the [User Name] and [Password] that are registered with the machine, then click [OK].Select [ID&Print] from [Output Method], then click [OK].Click [Print].Select [Logout after Print], enter your user name and password, then tap [Login].After successful user authentication, the file is printed.* Enter a keyword. You can search within the user's guide. The Secure Print function stores print jobs in the Secure Job box and outputs them after the user entered the password on the touch panel; therefore, it is convenient to output confidential documents.For Secure Print, specify a job using the printer driver when printing, and output it on the touch panel.In order to prevent information leakage, you can restrict printing done on this machine to secure printing only.Click the Workflow tab.Select Secure Print from the Output Method pull-down menu.At this time, Normal is automatically selected for Print Mode.Enter the Secure Print ID and Password. To specify the password, type Password, then enter the same password in Reenter.supplementary explanationPassword: 1 to 8 one-byte alphanumeric charactersClick OK to make prints.Click the Basic tab.Select Secure Print from the Output Method pull-down menu.supplementary explanationIf Secure Print ID and Password for Secure Print are not specified, the User Settings dialog box is displayed. Proceed to step 3.supplementary explanationWhen changing Secure Print ID and Password that are already specified, press User Settings. Proceed to step 3.supplementary explanationWhen not changing Secure Print ID and Password that are already specified, proceed to step 4.In the User Settings dialog box, enter Secure Print ID and Password.supplementary explanationPassword: 1 to 8 one-byte alphanumeric charactersClick OK to make prints.On the touch panel, press JOB LIST and then press Secure Job.Select the name that has the Secure Print ID specified on the printer driver for printing.Enter a set password in Secure Print, and then press OK.The print jobs in the User Box are displayed.Select a print job, then click Output.A dialog is displayed to specify the output method and number of copies.Select the desired one from Normal, Proof, Proof(1st), and Wait, enter the number of copies using the keypad on the control panel, then press OK.When print-out processing is completed, the print job is deleted from the User Box.For details about job editing functions on the JOB LIST screen, such as HDD Store, refer to [Secure Job] Screen. The purpose of this document is show the admin how to setup their printers so users will have to enter credentials every time they want to print in color. When they want to print black and white they will just have to use the public user which does not require credentialsAll instructions a based off the web portal. You can do this from the printers console if you want. And, this article assumes you know a little about how to navigate through the KM web portal.Go to the web portalLogin as the administratorGo to the User Auth/Account track tabGeneral SettingsIn the User Authentication dropdown select " ON (MFP)"In the Public User Access dropdown select ON (Without Login)leave the rest at their defaultsClick OK to save settingsWhile still in the User Auth/ Account track, click on User Authentication Setting on the left side bar.Select User RegistrationNew RegistrationEnter a UsernameEnter a PasswordRetype the passwordyou must have an icon so select an icon. it doesnt matter which.select the users permissions and allowanceClick OK at the bottom of the page.Rinse and repeat.Step 3: Set Public User RestrictionsWhile still in the User Auth/ Account track, click on Public User in the side bar2.Go to Output permissionsIn the Color dropdown box select RestrictClick OK Some printers may make you do this like the C220 or C203While still in the User Auth/ Account track, go to the Administrative Settings sidebar.In the ID & Print dropdown select OFFClick OK. To make sure the users will have to enter a password each time they print you must set this up. Some printers set this by default.Once you add the printer, go to the printer propertiesGo to the Settings TabCheck both the Verify Authentication settings before printing and Popup Authentication Dialog when printing.click apply.Note that even when printing in BW it will ask for a Username. By default the user is Public and does not require a password. To display: [Box][System][Secure Print]Select the file[Print][Application][Copy Security]Password Copy is a copy protection function that prints concealed security watermarks such as "Private" or a date in the background to prevent unauthorized copying, and embeds a password for the password copy function on all printed sheets.SettingsDescription[ON]/[OFF]Select [ON] to embed a password.[Password]Enter the password to restrict copying.[Stamp Setting]Set a stamp to be printed on each sheet of paper.[Stamp Text]Select a stamp used. The date and time can also be printed.[Preset Stamp]: Select a preset stamp to be printed.[Date/Time]: Select a format (type) of date and time to be printed.[Other]: Specify the job number, the machine's serial number, and distribution control number to be printed.[Stamp Selection]The registration status of the stamp is displayed.[Detail Setting]If necessary, select the print size and text color.[Password Copy]Specify the contrast of password copy guard pattern if necessary.[Background Pattern]Select a background pattern.TipsYou can use the Password Copy function when the Security Kit is installed and the Password Copy function is enabled on this machine.The Password Copy function does not support color paper, envelopes and transparencies.

Konica minolta password setup. Konica minolta printer settings. What is the default password for konica minolta printer. How do i change the default print settings on my konica minolta. What is the default admin password for konica minolta printer. Konica minolta password print. Password konica minolta.